



Single Channel LoRa IoT Kit v2 User Manual

Document Version: 1.0.6

Version	Description	Date
1.0.0	Release	2019-Jan-28
1.0.1	Modify limitation words	2019-May-10
1.0.2	Add description of MQTT publish format	2019-Jun-15
1.0.3	Add ThingSpeak downlink example, and Video Link	2019-Jun-19
1.0.4	Correct broken links.	2019-Jun-25
1.0.5	Add trouble shooting for Arduino 1.8.10, add CN470 support, Change Cayenne to Mydevices	2019-Oct-25
1.0.6	Add Password	2020-Nov-24

Index:

1	Overview	4
1.1	What is Dragino Single Channel LoRa IoT Kit v2?	4
1.2	What can you learn from the kit?.....	4
1.3	What parts Dragino LoRa IoT v2 includes?.....	5
2	Preparing.....	6
2.1	Software for End Node	6
2.1.1	Install Arduino IDE and CH340 driver.....	6
2.1.2	Install LoRa Library for Arduino.....	7
2.2	Prepare for LG01-N Gateway.....	8
2.2.1	Configure LG01-N for internet connection	8
2.2.2	Download putty tool to access LG01-N via SSH	11
3	Example 1: Test a LoRaWAN network	12
3.1	Typology and Data Flow	13
3.2	Create a gateway in TTN Server.....	14
3.3	Configure LG01-N Gateway	16
3.3.1	Configure to connect to LoRaWAN server	16
3.3.2	Configure LG01-N's LoRa Radio frequency	17
3.4	Create LoRa Shield End Node	18
3.4.1	Hardware Connection	18
3.4.2	Set up OTAA device in TTN and upload sketch to UNO	18
3.4.3	Configure to connect to Mydevices Application Server.....	22
3.4.4	Use downlink message to control relay	26
3.4.5	Test with Interrupt	28
3.5	Create LoRa/GPS Shield End Node	29
3.5.1	Hardware connection.....	29
3.5.2	Set up ABP device in TTN and upload software to UNO.....	29
3.6	Conclusion and limitation.....	33
3.6.1	Overview for the example.....	33
3.6.2	Limitations.....	35
4	Example 2: Test with a MQTT IoT Server	37
4.1	Typology and Data Flow	37
4.2	Set up sensor channels in ThingSpeak	38
4.3	Simulate MQTT uplink via PC's MQTT tool.....	40
4.4	Try MQTT Publish with LG01-N Linux command.....	41
4.5	Configure LG01-N Gateway	43
4.5.1	Publish Logic.....	43
4.5.2	Configure LG01-N's Radio frequency	44
4.6	Create LoRa Shield End Node	46
4.6.1	Hardware Connection	46
4.6.2	Test with uplink	47
4.6.3	Test with interrupt by flame detect	48

4.6.4	Test with downlink	50
4.7	Conclusion and limitation.....	52
4.7.1	Overview for the example.....	52
5	Order Info.....	53
6	FAQ & Trouble Shooting.....	54
6.1	I can't upload sketch to LoRa Shield in MAC OS, shows "dev/cu.usbmodem1421 is not available "	54
6.2	My IoT Kit has the model LG01-P instead of LG01-N, Can I still use this manual.	54
6.3	Duplicate library issue while upload in Arduino IDE 1.8.10.	55
6.4	How can I set to use CN470 band?.....	56
7	Technical Support.....	57
8	Reference	58

1 Overview

1.1 What is Dragino Single Channel LoRa IoT Kit v2?

Dragino Single Channel LoRa IoT Kit v2 is designed to facilitate beginners and developers to quickly learn LoRa and IoT technology. It helps users to turn the idea into a practical application and make the Internet of Things a reality. It is easy to program, create and connect your things everywhere. A number of telecom operators are currently rolling out networks, but because LoRa operates in the open spectrum you can also set up your own network.


The LoRa IoT kit v2 shows how to build a LoRa network, and how to use the network to send data from a LoRa sensor node to the cloud server. Depends on the actually use environment, the LoRa gateway will connect your other LoRa nodes up to 500 ~ 5,000 meters.

1.2 What can you learn from the kit?

The goals through this LoRa IoT kit v2:

- ✓ Understand the structure of an Internet of Things network, and how does an IoT network works
- ✓ Learn coding method for Arduino micro controller
- ✓ Learn some common sensors.
- ✓ Learn some basic commands for Linux and
- ✓ Learn about LoRa and how to set up a LoRa network.
- ✓ Learn different way to connect LoRa network to IoT Server and compare their advantages / disadvantages.

1.3 What parts Dragino LoRa IoT v2 includes?



Single Channel LoRa IoT Kit Packing List.

- ✓ 1 x [LG01-N](#) single channel LoRa Gateway
- ✓ 1 x LoRa end node ([LoRa Shield](#) + Arduino UNO)
- ✓ 1 x LoRa end node ([LoRa/GPS Shield](#) + Arduino UNO)
- ✓ 1 x flame Sensor
- ✓ 1 x relay
- ✓ 1 x photosensitive sensor
- ✓ 1 x buzzer
- ✓ 1 x ultrasonic sensor
- ✓ 1 x DHT11 temperature and humidity sensor
- ✓ 20 x dupont cable (male to male)
- ✓ 20 x dupont cable (female to female)
- ✓ 20 x dupont cable (male to female)

2 Preparing

In the kit, there are two LoRa End Node, they are LoRa Shield + UNO and LoRa/GPS Shield + UNO. Both of them use Arduino UNO as MCU to control the LoRa transceiver.


We need to program the Arduino UNO during our testing to support the required functions for end nodes. To finish this, we need to install some software and library first.

2.1 Software for End Node


2.1.1 Install Arduino IDE and CH340 driver

First download and install [Arduino IDE](#). This is the tool to program the Arduino UNO.


The Arduino UNO in the kit is clone version and is equipped with CH340 USB to UART chip. We need to install CH340 driver in the PC to let the Arduino IDE program it via USB. If we successful install the driver, a com port will show in the system device manager:



After install the driver, start Arduino and we will be able to use the board Arduino UNO and corresponding COM port to program UNO now.



We can enable compilation and upload in Arduino → File → Preference. This will help us in debug.



2.1.2 Install LoRa Library for Arduino


In our examples, we will use two different LoRa libraries for End Node to build different type of LoRa network. They are:

- [Arduino-LMIC](#): LoRaWAN library to configure the End node as a standard LoRaWAN end node.
- [LoRa-raw](#): This is a simple library for LoRa transmit & receive, all data transfer without ID control, encryption. If user wants to develop a LoRa network with private LoRa protocol, he can modify base on this Library.

We also need to install some libraries to connect to different sensors:

- [DHTlib](#): This is the library to use DHT11 temperature & humidity sensor.
- [TinyGPS](#): Library for LoRa GPS Shield to get the GPS data.

Download all above libraries and put them in the [Arduino → Libraries](#) directory



2.2 Prepare for LG01-N Gateway

In LoRa IoT Kit v2, we use LG01-N as LoRa Gateway. Unlike LG01-P in v1 kit, the LG01-N has its own LoRa utility and not need to program it via Arduino. Since we need to connect to Internet IoT Server, we need to configure the LG01-N to have internet access.

2.2.1 Configure LG01-N for internet connection.

Below steps show how to set up LG01-N to use WiFi for internet access.

Step1:

Connect PC to LG01-N's LAN port via RJ45 cable and set up PC Ethernet port to DHCP.

PC will then get IP from LG01-N. The ip range is 10.130.1.xx

Use browser to access the LG01-N via IP 10.130.1.1. (Recommend use Chrome here)

User can also connect to the wifi AP network from LG01-N, the **wifi password** is **dragino+dragino**.

Step2:

Open a browser in the laptop and type


<http://10.130.1.1/cgi-bin/luci/admin>

User will see the login interface of LG01-N.

The account for Web Login is:

User Name: root

Password: dragino



Step3:

In network -> Wireless, select radio0 interface and scan.



radio0: Master "dragino-1b8288"

Wireless Overview



Generic MAC80211 802.11bgn
Channel: 11 (2.462 GHz) | Bitrate: ? Mbit/s

Restart

Scan

Add



SSID: dragino-1b8288 | Mode: Master
BSSID: A8:40:41:1B:82:88 | Encryption: None

Disable

Edit

Remove

Step4:

Select the wireless AP and join the wifi network:



Status ▾ System ▾ Network ▾ Service ▾ Logout

AUTO REFRESH ON

Join Network: Wireless Scan

Signal	SSID	Channel	Mode	BSSID	Encryption	
100%	dragino-office	8	Master	50:64:2B:1A:B8:4D	mixed WPA/WPA2 - PSK	Join Network
84%	ChinaNet-gLnb	2	Master	A4:29:40:66:F4:E7	mixed WPA/WPA2 - PSK	Join Network



Status ▾ System ▾ Network ▾ Service ▾ Logout

Joining Network: "dragino-office"

Replace wireless configuration

Check this option to delete the existing networks from this radio.

WPA passphrase

***** *

Specify the secret encryption key here.

Name of the new network

wwan

The allowed characters are: A-Z, a-z, 0-9 and _

Create / Assign firewall-zone

wan: wan:

Choose the firewall zone you want to assign to this interface. Select *unspecified* to remove the interface from the associated zone or fill out the *create* field to define a new zone and attach the interface to it.

[Back to scan results](#)

Submit

Step5:

In network->wireless page, disable WiFi AP network. Notice: After doing that, you will lose connection if your computer connects to the LG01-N via its WiFi network.

radio0: Master "dragino-1b8288"

Wireless Overview

 radio0	Generic MAC80211 802.11bgn Channel: 11 (2.462 GHz) Bitrate: ? Mbit/s	<button>Restart</button> <button>Scan</button> <button>Add</button>
 0%	SSID: dragino-1b8288 Mode: Master BSSID: A8:40:41:1B:82:88 Encryption: None	<button>Disable</button> <button>Edit</button> <button>Remove</button>
 0%	SSID: dragino-office Mode: Client BSSID: 50:64:2B:1A:B8:4D Encryption: -	<button>Disable</button> <button>Edit</button> <button>Remove</button>

Associated Stations


Network	MAC-Address	Host	Signal / Noise	RX Rate / TX Rate
No information available				

(Note: make sure click the Save & Apply after configure)

After successful associate, the WiFi network interface can be seen in the same page and see LG01-N get the ip from the uplink router.

[WAN](#) [WWAN](#) [LAN](#)


Interfaces

 LAN br-lan	Protocol: Static address Uptime: 2h 0m 4s MAC: A8:40:41:1B:82:8B RX: 1.40 MB (13346 Pkts.) TX: 2.79 MB (10321 Pkts.) IPv4: 10.130.1.1/24	<button>Restart</button> <button>Stop</button> <button>Edit</button> <button>Delete</button>
 WAN eth1	Protocol: DHCP client MAC: A8:40:41:1B:82:8A RX: 4.30 MB (51840 Pkts.) TX: 55.77 KB (429 Pkts.)	<button>Restart</button> <button>Stop</button> <button>Edit</button> <button>Delete</button>
 WWAN Client "dragino-office"	Protocol: DHCP client Uptime: 0h 6m 6s MAC: A8:40:41:1B:82:88 RX: 549.38 KB (5659 Pkts.) TX: 14.90 KB (94 Pkts.) IPv4: 10.130.2.169/24	<button>Restart</button> <button>Stop</button> <button>Edit</button> <button>Delete</button>
Add new interface...		
Save & Apply Save Reset		

2.2.2 Download putty tool to access LG01-N via SSH

It will be helpful to see the LG01-N inside Linux system to understand the data flow and debug.

User can access to the Linux console via SSH protocol. Make sure your PC and the LG01-N is in the same network, then use a SSH tool (such as [putty](#)) to access it. Below are screenshots:




IP address: IP address of LG01-N

Port: 22

User Name: root

Password: dragino (default)

After log in, you will be in the Linux console and can input commands here.




So we have prepare what we need and let's go for the examples!

3 Example 1: Test a LoRaWAN network

This example describes how to use LG01-N, LoRa Shield & LoRa GPS Shield to set up a LoRaWAN network and connect it to [TTN LoRaWAN Server](#). It also shows how to use external application server to monitor / manage the LoRa Nodes.

LoRaWAN mode:

Use LG01N / OLG01N as a [LoRaWAN gateway*](#) to forward packet to LoRaWAN IoT Server

**Operate Principle:**

- LG01N/OLG01N running packet forward and will forward the uplink LoRa packet from end node to LoRaWAN server.
- It will also forward downlink LoRa packet from LoRaWAN server to end node.
- The end node can use OTAA or ABP mode in the LoRaWAN protocol.


Limitation:

- The LG01 only support one LoRaWAN frequency for uplink. So the end node should be set to fix frequency.
- If end node use multiply frequencies to transfer, The LG01 will only be able to receive the same frequency set in LG01N.

3.1 Typology and Data Flow

The network topology and dataflow for the example is as below:

Topology for Thethingsnetwork Connection:




In next section we will start to configure for this example.

3.2 Create a gateway in TTN Server

Step 1: Get a Unique gateway ID.


Every LG01-N has a unique gateway id. The id can be found at LoRaWAN page:




The screenshot shows the 'LoRa Gateway Settings' configuration page. The 'Gateway ID' field is highlighted with a red border and contains the value 'a840411b6fc44150'. Other fields include 'Service Provider' (The Things Network), 'Server Address' (ttn-router-eu), 'Server Port' (1700), 'Mail Address' (dragino-1b6fc4@dragino.com), 'Latitude' (22.73), 'Longitude' (114.23), and 'RadioMode' (A for RX, B for TX).

The gateway id is: **a840411b6fc44150**

Step 2: Sign up a user account in TTN server




Step 3: Create a Gateway in TTN



The screenshot shows the 'Gateways > Register' page in the The Things Network Console. The 'Gateway EUI' field contains the value 'A8 40 41 1b 6f c4 41 50'. The 'Frequency Plan' dropdown is set to 'Europe 868MHz'. The 'Router' dropdown is set to 'ttn-router-eu'. A yellow box highlights the 'Gateway ID' field, another highlights the 'Frequency Plan' dropdown, and a red box highlights the 'Router' dropdown and the 'I'm using the legacy packet forwarder' checkbox.

After create the gateway, we can see the gateway info, as below, the **Status** shows “not connected” because the LG01-N doesn’t configure to send update status yet.



The screenshot shows the 'GATEWAY OVERVIEW' page. The 'Status' field is highlighted with a red border and contains the value 'not connected'. Other visible fields include 'Gateway ID: eui-a840411b', 'Description: LG02-Gateway-1', 'Owner: edwin', 'Frequency Plan: Europe 868MHz', 'Router: ttn-router-eu', and 'Gateway Key'.

3.3 Configure LG01-N Gateway

3.3.1 Configure to connect to LoRaWAN server

We should configure the LG01-N now to let it connect to TTN network. Make sure your LG01-N has Internet Connection first.

Step1: Configure LG01-N to act as LoRaWAN forwarder mode



The screenshot shows the top navigation bar with "dragino-1893c4" and links for Status, System, Network, Service, and Logout. Below the navigation is a section titled "Single Channel LoRa Gateway" with the subtitle "Configuration to communicate with LoRa devices and LoRaWAN server". Under "LoRaWAN Server Settings", there is a dropdown menu for "IoT Service" set to "LoRaWan/Raw forwarder". Other settings include "Debug Level" set to "Little message output".

Single Channel LoRa Gateway

Configuration to communicate with LoRa devices and LoRaWAN server

LoRaWAN Server Settings

IoT Service	LoRaWan/Raw forwarder
Debug Level	Little message output

Step2: Input server info and gateway id

Choose the correct the server address and gateway ID.



The screenshot shows the top navigation bar with "dragino-1b8288" and links for Status, System, Network, Service, and Logout. Below the navigation is a section titled "LoRa Gateway Settings" with the subtitle "Configuration to communicate with LoRa devices and LoRaWAN server". Under "LoRaWAN Server Settings", several fields are highlighted with red boxes: "Service Provider" (The Things Network), "Server Address" (ttn-router-eu), and "Server Port" (1700). Other fields include "Gateway ID" (a840411b), "Mail Address" (edwin@dragino.com), "Latitude" (22.73), and "Longitude" (114.23).


LoRa Gateway Settings

Configuration to communicate with LoRa devices and LoRaWAN server

Service Provider	The Things Network
Server Address	ttn-router-eu
Server Port	1700
Gateway ID	a840411b
Mail Address	edwin@dragino.com
Latitude	22.73
Longitude	114.23

Check Result

After above settings, the LG01-N will be able to connect to TTN, as shown in below:



The screenshot shows the "GATEWAY OVERVIEW" section with the following details:

- Gateway ID: eui-a840411b
- Description: L Office-868
- Owner: edwin (with a profile icon)
- Status: connected
- Frequency Plan: Europe 868MHz
- Router: ttn-router-eu

3.3.2 Configure LG01-N's LoRa Radio frequency

Now we should configure LG01-N's radio parameter to receive the LoRaWAN packets. We are using 868.1Mhz and other parameters as below:

Radio Settings


Radio settings for Channel

Frequency (Unit:Hz)	868100000
Spreading Factor	SF7
Coding Rate	4/5
Signal Bandwidth	125 kHz
Preamble Length	8 <small>Length range: 6 ~ 65536</small>
LoRa Sync Word	52 <small>Value 52(0x34) for LoRaWAN</small>
Encryption Key	Encryption Key

This parameters set is for uplink (receive data for LoRa End Node).According to LoRaWAN spec, the downlink radio parameters frequency is defined by network server (TTN). LG01-N will adjust downlink parameters according to info from TTN.

3.4 Create LoRa Shield End Node

3.4.1 Hardware Connection




There are three sensors connect to the LoRa Shield + UNO. These sensors are flame sensors, DHT11 (Temperature & Humidity sensor) and Relay. Please use the connection as we show in the photo.

Note: There is a trick in above connection, the relay connects to VIN. In this case, The UNO can only be power via USB port. If user need to power via DC power adapter, please use another 5v pin to power the relay.

3.4.2 Set up OTAA device in TTN and upload sketch to UNO

Here we set up the LoRa Shield + UNO as an OTAA device in TTN. We will tell the difference of OTAA and ABP mode later.

Step 1: Create an OTAA device in TTN server -- > Application page.



The screenshot shows the TTN Application page with the following sections:

- APPLICATION EUIS:** Displays the EUIS (70 B3 D5 7E F0 00 46 18).
- DEVICES:** Shows 5 registered devices.

dragino_test_application1 > Devices > otaa-device-1 > Settings

Device EUI
The serial number of your radio module, similar to a MAC address

A8 40 41 12 34 56 78 90	8 bytes
-------------------------	---------

Application EUI

70 B3 D5 7E F0 00 46 18

Activation Method

OTAA	ABP
-------------	-----

App Key
The key your device will use to set up sessions with the network

C3 95 15 93 AD 55 1A 83 2F 31 25 B6 7A F5 74 1D	16 bytes
---	----------

For this device, set up to use Cayenne payload, so TTN can parse the sensor data properly.

Overview Devices **Payload Formats** Integrations Data Settings

PAYLOAD FORMATS

Payload Format
The payload format sent by your devices

Cayenne LPP

Step 2: Modify the LMIC library

To use LoRaWAN with LG01-N, we need to modify the LMIC library to support single channel mode.

Find the [Arduino LMIC](#) install path in Arduino library. Before compiling the code, user needs to change the Frequency Band to use with LG01-N. The change is in the file `arduino\libraries\arduino-lmic\src\lmic\config.h`. Changes are as below:

```
#define CFG_eu868 1
#define CFG_us915 1
#define CFG_au921 1
#define CFG_as923 1
#define CFG_in866 1

#define LG02_LG01 1

//US915: DR_SF10=0, DR_SF9=1, DR_SF8=2, DR_SF7=3, DR_SF8C=4
// DR_SF12CR=8, DR_SF11CR=9, DR_SF10CR=10, DR_SF9CR=11, DR_SF8CR=12, DR_SF7CR
#if defined(CFG_us915) && defined(LG02_LG01)
    LG02_UPFREQ: End Device Uplink Frequency
    LG02_DNWFRQ: End Device Uplink Frequency
    LG02_RXSF: End Device Uplink (transmit) SF
    LG02_TXSF: End Device Downlink (receive) SF
#define LG02_RXSF 3 // DR_SF7
#define LG02_TXSF 8 // DR_SF12CR
    The TXSF is now set to default value:
    US915/AS923 : 923300000 , SF12BW500
    EU868: 869525000, SF12BW125
#endif

//EU868: DR_SF12=0, DR_SF11=1, DR_SF10=2, DR_SF9=3, DR_SF8=4, DR_SF7=5, DR_SF7B=1, DR_FSK, DR_NONE
#define LG02_UPFREQ 868100000
#define LG02_DNWFRQ 869525000
#define LG02_RXSF 5 // DR_SF7
#define LG02_TXSF 0 // DR_SF12CR
#endif
```

Choose the Frequency Band, same as in LoRaWAN server

uncomment this for LG01 / LG02

Step 3: Input keys in Arduino Sketch and upload to device.

The sketch for this example is [lora_shield_cayenne_and_ttn-otaaClient.ino](#). Download and open it, we need to modify the keys to match the keys in TTN. Get Device EUI/Application EUI & APP Key from TTN and put them in the sketch, make sure the Device EUI and Application Key are lsb and the APP key is msb.

Application ID: dragino_test_application1
 Device ID: otaa-device-1
 Activation Method: OTAA

Device EUI: { 0x90, 0x78, 0x56, 0x34, 0x12, 0x41, 0x40, 0xA8 }
 Application EUI: { 0x18, 0x46, 0x00, 0xF0, 0x7E, 0xD5, 0xB3, 0x70 }
 App Key: { 0xC3, 0x95, 0x15, 0x93, 0xAD, 0x55, 0x1A, 0x83, 0x2F, 0x31, 0x25, 0xB6, 0x7A, 0xF5, 0x74, 0x1D }

Device Address: 26 01 2D 5E
 Network Session Key:
 App Session Key:

ttn-otaa

```
#include "SPT.h"


// This EUI must be in little-endian format, so least-significant-byte
// first. When copying an EUI from ttncctl output, this means to reverse
// the bytes. For TTN issued EUIs the last bytes should be 0xD5, 0xB3,
// 0x70.
static const ul_t PROGMEM APPDEVEUI[8]={ 0x18, 0x46, 0x00, 0xF0, 0x7E, 0xD5, 0xB3, 0x70 };

void os_getArtEui (ul_t* buf) { memcpy_P(buf, APPDEVEUI, 8); }

// This should also be in little endian format, see above.
static const ul_t PROGMEM DEVEUI[8]={ 0x90, 0x78, 0x56, 0x34, 0x12, 0x41, 0x40, 0xA8 };
void os_getDevEui (ul_t* buf) { memcpy_P(buf, DEVEUI, 8); }

// This key should be in big endian format (or, since it is not really a
// number but a block of memory, endianness does not really apply). In
// practice, a key taken from ttncctl can be copied as-is.
// The key shown here is the semtech default key.
static const ul_t PROGMEM APPKEY[16] = { 0xC3, 0x95, 0x15, 0x93, 0xAD, 0x55, 0x1A, 0x83, 0x2F, 0x31, 0x25, 0xB6, 0x7A, 0xF5, 0x74, 0x1D };
void os_getDevKey (ul_t* buf) { memcpy_P(buf, APPKEY, 16); }
```

Upload the code to UNO:



Step 4: Analyze output result

From output of LoRa Node Serial Monitor, we can see it send Joining after start(TX), then get join ACK (RX), then upload the data to TTN (TX).

```

1 //*****#
2 * Copyright (c) 2019
3 *
4 * Permission is here
5 * obtaining a copy of
6 * to do whatever they
7 * including, but not
8 * NO WARRANTY OF ANY
9 *
10 * This example sends
11 * world!, using fre
12 * the The Things Netw
using proxy DIRECT
Using proxy DIRECT
Using proxy DIRECT

```

Connect to TTN and Send data to mydevice cayenne(Use DHT11 Sensor):
RXMODE_RSSI
COUNT=1 #####
The temperature and humidity:
[28.00°C, 63.00%]
6024: engineUpdate, oemode=0x8
Packet queued
9013: EV_JOINING
10182: engineUpdate, oemode=0xc
196226: engineUpdate, oemode=0xc
196532: TXMODE, freq=868100000, len=23, SF=7, BW=125, CR=4/5, IH=0
503011: RXMODE_SINGLE, freq=868100000, SF=7, BW=125, CR=4/5, IH=0, rxsysms=255
514692: JaccRX1, dataLen=33
515265: EV_JOINED
515290: engineUpdate, oemode=0x808
516157: TXMODE, freq=868100000, len=20, SF=7, BW=125, CR=4/5, IH=0
570725: RXMODE_SINGLE, freq=868100000, SF=7, BW=125, CR=4/5, IH=0, rxsysms=255

From gateway logread, we can see the data send from end node (txpk), dats get from server(rxpk).

In TTN-Gateway page, we can also see the traffic.

ONSO IMMUNITY

TTN Traffic Page shows the device status


Gateways > eui-a840411b6fb04150 > Traffic beta

▲ 23:56:34	868.1	lora	4/5	SF 7 BW 125	61.7	
▲ 23:55:30	868.1	lora	4/5	SF 7 BW 125	61.7	Immediately send an Uplink message after join success
▲ 23:54:27	868.1	lora	4/5	SF 7 BW 125	61.7	
▲ 23:53:24	868.1	lora	4/5	SF 7 BW 125	61.7	
▲ 23:52:20	868.1	lora	4/5	SF 7 BW 125	61.7	
▲ 23:51:17	868.1	lora	4/5	SF 7 BW 125	61.7	TTN Send a Join reply. LoRa End node must get this packet to finish Join. The frequency shows use 868.1MHz frequency, must be the same as the "LG02_DNWRFREQ" in Lmic config.c file
▲ 23:51:16	868.1	4/5	SF 7 BW 125	71.9		
▲ 23:51:12	868.1	4/5	SF 7 BW 125	61.7	TTN Get Join request	

Note: The LG02_DNWREQ value in Arduino_LMIC/src/lmic/config.h should match downlink frequency from TTN.

TTN shows 868.1 here, So LG02_DNWREQ should be 868100000



After success Joined, we can see the data in the device page:



3.4.3 Configure to connect to Mydevices Application Server

In TTN, we can see the raw data, now we try to connect it to the application server.

Step 1: Add Mydevice in Application page



Applications >  Isn50-test111 > Integrations

ADD INTEGRATION

 **MyDevices** (v2.6.0)
myDevices
Quickly design, prototype and commercialize IoT solutions with myDevices Cayenne
[documentation](#)

Process ID
The unique identifier of the new integration process
 

Access Key
The access key used for downlink

3 

[Cancel](#) **Add integration**

Step2: Log in [Mydevices account](#) and add devices.


The screenshot shows the Cayenne MyDevices interface. On the left, a sidebar menu has 'Device/Widget' selected (marked with a red arrow 1). The main area displays a grid of LoRa module manufacturers: acklio, actility, citykinect, everynet, kerlink, LORIOT, Objeniöus, OrbiWise, pixelnetworks, Sagemcom, SEMTECH, senet, SenRa, Spark, Stream, swisscom, THE THINGS NETWORK, and X-TELIA. A red arrow 2 points to the X-TELIA logo.

This screenshot shows the Cayenne MyDevices interface with a different view. The sidebar menu now lists various device categories like Arduino, Single Board Computers, MicroControllers, Sensors, Actuators, Extensions, and LoRa modules. A red arrow 1 points to the 'Devices & Widgets' section. The main area shows a list of available development kits: Dragino Technology Development Kit (selected), Zenseio Development Kit, and others. A red arrow 2 points to the Dragino Technology Development Kit entry.

Add DevEUI of the End node

The screenshot shows the 'Enter Settings' page for adding a new device. The device is identified as a 'Dragino Technology Development Kit'. The 'Name' field contains 'Dragino Technology Development Kit'. The 'DevEUI' field is highlighted with a red arrow 1 and contains the placeholder 'your DevEUI'. The 'Activation Mode' dropdown is set to 'Already Registered'. Below this, the 'Tracking' section shows a location entry: 'Location' is set to 'This device doesn't move', and the 'Independence, KS 67301美国' field is highlighted with red arrows 2 and 3. A large green 'Add device' button is at the bottom.

After above steps, we can now see the sensor data in Mydevices:



3.4.4 Use downlink message to control relay


We can use either TTN or Cayenne to control the relay.

Control relay via TTN:

The string for ON is: 03 00 64 FF

The string for OFF is: 03 00 00 FF

In put above value in the TTN Downlink payload, we can see the relay can switch between different states, since we are in Class A, the downlink will only happen after each uplink.



The screenshot shows two parts of the The Things Network Console interface.

Top Section (Downlink Configuration):


- Scheduling:** Options include "replace", "first", and "last".
- FPort:** Set to 1.
- Confirmed:** Checked.
- Payload:** Set to "bytes" and contains the value "03 00 64 FF". A red box highlights this value, and a red arrow labeled "1" points to it.
- Send:** A green button at the bottom right.

Bottom Section (Application Data):

- Filters:** Options include "uplink", "downlink", "activation", "ack", and "error".
- Overview:** Shows a timeline of events. A red box highlights the event at 11:41:43, and a red arrow labeled "Send downlink success and reply" points to it.
- Data:** Shows a list of events with columns: time, counter, port, payload, digital_in_4, digital_out_3, and relative_humidity_2.
- Relay States:** Two annotations with arrows point to specific entries:
 - An annotation labeled "Relay is on" points to the entry at 11:40:58 with payload "01 67 00 E6 02 68 58 03 01 01 04 00 01" and digital_out_3: 1.
 - An annotation labeled "Relay is off" points to the entry at 11:41:29 with payload "03 00 64 FF" and digital_out_3: 0.

Control relay via Cayenne

In Cayenne, just click the digital output button, it will auto send out the command strings: ON: 03 00 64 FF , OFF is: 03 00 00 FF



Cayenne will pass the string to TTN and TTN will show as above. In the serial monitor of End Node, we can see below output if downlink string arrives:

```

lora_shield_cayenne_and_ttn_abpClient | Arduino 1.8.5
文件 编辑 项目 工具 帮助
lora_shield_cayenne_and_ttn_abpClient
49 static const u1_t PROGMEM APPSKEY
50
51 // LoRaWAN end-device address (De
52 static const u4_t DEVADDR = 0x260
53
54 // These callbacks are only used
55 // left empty here (we cannot lea
56 // DISABLE_JOIN is set in config
57 void os_getArtEui (u1_t* buf) {
58 void os_getDevEui (u1_t* buf) {
59 void os_getDevKey (u1_t* buf) {
60

avrduke done. Thank you.

[25.00°C, 66.00%]
3955087: engineUpdate, opmode=0x908
3957856: TXMODE, freq=868100000, len=23, SF=7, BW=125, CR=4/
Packet queued
4012411: RXMODE_SINGLE, freq=868100000, SF=7, BW=125, CR=4/5
4022496: Received downlink, window=RX1, port=1, ack=0
4022541: EV_TXCOMPLETE (includes waiting for RX windows)
Received :
3 0 64 FF
Set pin to HIGH.


4028292: engineUpdate, opmode=0x810
4030903: TXMODE, freq=868100000, len=12, SF=7, BW=125, CR=4/
4085487: RXMODE_SINGLE, freq=868100000, SF=7, BW=125, CR=4/5
4124275: RXMODE_SINGLE, freq=869525000, SF=9, BW=125, CR=4/5
4188702: EV_TXCOMPLETE (includes waiting for RX windows)
4188747: engineUpdate, opmode=0x900

```

3.4.5 Test with Interrupt

The temperature & humidity in this example are updated periodically (once several minutes/hours), in some case, we need to update the data once an action is happen. So we need to use interrupt.


The DO pin of Flame sensor is high in normal case. While it detects a flame, this pin will become low and act as an external interrupt for Arduino. The Arduino UNO will then immediately upload the temperature and humidity to TTN




The screenshot shows the 'APPLICATION DATA' section of the The Things Network Console. It lists uplink messages. The fourth message from the top is highlighted with a red box around the 'digital_in_4: 0' value. A red arrow points from the text 'The flame sensor interrupt' to this value. The message details are as follows:

time	counter	port	payload	digital_in_4	digital_out_3	relative_humidity_2
11:29:51	6	1	01 67 00 E6 02 68 5A 03 01 00 04 00 01	1	0	45
11:29:28	5	1	01 67 00 E6 02 68 5A 03 01 00 04 00 00	0	0	45
11:29:21	4	1	01 67 00 E6 02 68 5A 03 01 00 04 00 01	1	0	45
11:28:58	3	1	01 67 00 E6 02 68 5A 03 01 00 04 00 00	0	0	45

Then we can see on the cayenne:



The screenshot shows the Cayenne IoT Platform interface. On the right, there's a summary card for the 'Dragino Technology Development Kit'. The 'Digital Input (4)' section shows a red arrow pointing to a waveform icon with the text 'Have fire.the DO pin of flame sensor is low'. On the left, a sidebar lists various device types, and the main area shows a map with a blue location marker.



The screenshot shows the Arduino IDE interface. On the left, the code for the LoRa/GPS Shield is displayed:

```

230 void setup() {
231     Serial.begin(9600);
232     while(!Serial);
233     Serial.println("Connect");
234
235     pinMode(ctl_pin, OUTPUT);
236     pinMode(flame_pin, INPUT);
237     attachInterrupt(1, fire, RISING);
238
239 #ifdef VCC_ENABLE
240 // For Pinoccio Scout board
241     pinMode(VCC_ENABLE, OUTPUT);

```

On the right, the serial monitor window shows the output of the code. A red box highlights the temperature and humidity data sent via MQTT:

```

3002238: engineUpdate, opmode=0x908
Have fire, the tem#####
The temperature and humidity:
[23. 00°C, 45. 00%]
3003454: engineUpdate, opmode=0x108
Haveerature is send
#####
The temperature and humidity:
[23. 00°C, 45. 00%]
3010302: engineUpdate, opmode=0x108
Have fire, the temperature is send
3109920: engineUpdate, opmode=0x108
3110383: TXMODE, freq=868100000, len=26, SF=7, BW=125, CR=4/5, IH=0
3166736: RXMODE_SINGLE, freq=868100000, SF=7, BW=125, CR=4/5, IH=0, rxsysms=255
3205524: RXMODE_SINGLE, freq=869525000, SF=9, BW=125, CR=4/5, IH=0, rxsysms=255
3269940: EV_TXCOMPLETE (includes waiting for RX windows)
3269986: engineUpdate, opmode=0x900


```

At the bottom of the serial monitor, the message "avrduke done. Thank you." is visible.

3.5 Create LoRa/GPS Shield End Node

3.5.1 Hardware connection

The method to use LoRa/GPS Shield is similar with LoRa Shield. Below is the hardware connection of LoRa GPS Shield.



3.5.2 Set up ABP device in TTN and upload software to UNO

In LoRa Shield, we set up OTAA for connection. In this example, we will try ABP mode.

[Step 1](#): Create an ABP device in TTN server -- > Application page. And change it to ABP mode.

Applications > dragino_test_application1

APPLICATION EUIS

<> 70 B3 D5 7E F0 00 46 18

DEVICES
[register device](#)


5 registered devices

Applications > dragino_test_application1 > Devices > edwintest1 > Settings

[Overview](#) [Data](#) **Settings**
DEVICE SETTINGS
[General](#)

Location

SETTINGS
Description

A human-readable description of the device

Device EUI

The serial number of your radio module, similar to a MAC address

<> 00 BA DE A0 36 70 68 72

8 bytes

Application EUI

70 B3 D5 7E F0 00 46 18

Activation Method

OTAA

ABP
Step 2: Input keys into Arduino Sketch.

 The sketch for the LoRa /GPS Shield is [LoRa GPS Sketch code](#)

Applications > dragino_test_application1 > Devices > edwintest1

[TTN LoRaWAN End Device page](#)

 Application ID **dragino_test_application1**

Device ID edwintest1

 Activation Method **ABP**

Device EUI <> 00 BA DE A0 36 70 68 72

Application EUI <> 70 B3 D5 7E F0 00 46 18

 Make sure the Network
Session Key and App Session
Key are in MSB order

Device Address <> 26 01 1C 22

Network Session Key <> msb { 0x9A, 0xEA, 0xD0, 0x93, 0x06, 0xE3, 0x2B, 0x73, 0xDD, 0x54, 0x7B, 0x8B, 0xFF, !!! }

App Session Key <> msb { 0xB6, 0x07, 0x5B, 0xB5, 0xE4, 0xCE, 0x40, 0xA2, 0xA3, 0xEE, 0x7B, 0xDF, 0xDC, !!! }

ttn-abp

Arduino Sketch ttn-abp

Input the keys from TTN


```
#include <lmic.h>
#include <hal/hal.h>
#include <SPI.h>

// LoRaWAN NwksKey, network session key
// This is the default Semtech key, which is used by the early prototype TTN
// network.
static const PROGMEM u1_t NWKSKEY[16] = { 0x9A, 0xEA, 0x0D, 0x93, 0x06, 0xE3, 0x2B, 0x73, 0xDD, 0x54, 0x7B, 0x8B, 0xFF, 0xDC, 0x20, 0xF9 };

// LoRaWAN AppSKey, application session key
// This is the default Semtech key, which is used by the early prototype TTN
// network.
static const u1_t PROGMEM APPSKEY[16] = { 0xB6, 0x07, 0x5B, 0x85, 0xE4, 0xCE, 0x40, 0xA2, 0xA3, 0xEE, 0x7B, 0xDF, 0xDC, 0x23, 0x0E, 0x2B };

// LoRaWAN end-device address (DevAddr)
static const u4_t DEVADDR = 0x26011C22; // Change this address for every node!
```

Choose Arduino UNO to upload the sketch to LoRa GPS Shield and UNO



All other steps are similar with how we use with LoRa Shield.

Below are the outputs for reference:


Output from LoRa GPS Shield:

The Serial Monitor window displays the following log output:

```
803657: engineUpdate, opmode=0x808
809092: TXMODE, freq=868100000, len=24, SF=7, BW=125, CR=4/5, IH=0
867344: RXMODE_SINGLE, freq=868100000, SF=7, BW=125, CR=4/5, IH=0, rxsyms=255
906132: RXMODE_SINGLE, freq=869525000, SF=9, BW=125, CR=4/5, IH=0, rxsyms=255
970667: EV_TXCOMPLETE (includes waiting for RX windows)
971317: engineUpdate, opmode=0x900
#####
NO.1 #####
The longitude and latitude and altitude are:
[114.21, 22.72, 120.30]
4786638: engineUpdate, opmode=0x908
4791947: TXMODE, freq=868100000, len=24, SF=7, BW=125, CR=4/5, IH=0
Packet queued
4850199: RXMODE_SINGLE, freq=868100000, SF=7, BW=125, CR=4/5, IH=0, rxsyms=255
4888923: RXMODE_SINGLE, freq=869525000, SF=9, BW=125, CR=4/5, IH=0, rxsyms=255
4953334: EV_TXCOMPLETE (includes waiting for RX windows)
4953379: engineUpdate, opmode=0x900
```

At the bottom of the monitor, it says 'avrduke done. Thank you.'


Upload GPS data to TTN:




The screenshot shows the 'Data' section of the The Things Network Console. The URL is [Applications > lora-shield > Devices > gps-shield-otta > Data](#). The 'APPLICATION DATA' table lists several uplink messages. The columns are time, counter, port, payload, and GPS coordinates (latitude and longitude). The last message at 7:50:08 has a payload of 03 88 03 77 A5 11 6D4C 00 2E FE and GPS coordinates 120.3, 22.7237.

time	counter	port	payload	gps_3.latitude	gps_3.longitude
17:54:23	5	1	03 88 03 77 A5 11 6D4C 00 2E FE	120.3	22.7237
17:53:19	4	1	03 88 03 77 A5 11 6D4C 00 2E FE	120.3	22.7237
17:52:15	3	1	03 88 03 77 A5 11 6D4C 00 2E FE	120.3	22.7237
17:51:12	2	1	03 88 03 77 A5 11 6D4C 00 2E FE	120.3	22.7237
7:50:08	1	1	03 88 03 77 A5 11 6D4C 00 2E FE	120.3	22.7237


Output in Cayenne:



The screenshot shows the Cayenne interface with a project titled 'Dragino Technology Development'. The left sidebar shows device types like Arduino, Device 2.1fe, and Dragino. Under 'Dragino Technology Dev...', there are three 'GPS (3)' entries. The main area shows a map of a road with a red pin indicating the device's location. A 'Settings' button is highlighted with a red arrow labeled '2'.



The screenshot shows the 'Location' dialog in Cayenne. The 'General' tab is selected. It shows a dropdown menu for 'Location' with 'GPS' selected, indicated by a red arrow labeled '1'. Below it is a dropdown for 'GPS' and a 'Physical Address' input field. At the bottom are 'Remove' and 'Save' buttons, with 'Save' highlighted by a red arrow labeled '2'.



3.6 Conclusion and limitation

3.6.1 Overview for the example

This example shows how to set up a simple LoRaWAN network with public server. The LoRaWAN specification is for easy deploy the IoT network base on LoRa wireless. It contains the encryption, MAC control, device management etc. More info about LoRaWAN, please see [this link](#).

There are some frequently ask points for the example:

1/ Difference between OTAA & ABP mode:

We have tested OTAA and ABP mode for LoRaWAN. They are two different modes. In OTAA mode, we can see the device will send a join request, the IoT server will send back a Join confirm with dynamic device address, network session key and app session key. Then the device will use these key to communicate with the LoRaWAN server. This make sure the device will only communicate with one server.

In ABP mode, it will use the FIX device address, network session key and app session key. It doesn't have join process. So in theory, any server with match keys is possible to decrypt the data from this end device.

We can see OTAA has better security than ABP mode.

2/ AES 128 encryption:

The data between end device and server are AES128 encryption. So the gateway can't parse the packets, it just forward them.

3/ LoRaWAN Network Server:

A LoRaWAN network server is necessary in a LoRaWAN network for device control/management/data management. If user wants to build the NS , there are some open sources LoRaWAN NS such as [LoRaServer](#) can be used. And some gateways already include LoRaWAN NS (this is also a plan for LG01-N).

4/ Downlink message

In this example, we use LoRaWAN Class A. The end node will open two short downlink windows after each uplink. More info about LoRaWAN class A, please refer [LoRaWAN specification](#).

3.6.2 Limitations

The LG01-N is a single channel gateway (Same for LG02). And there are limitations:

1/ It works only on one frequency at a time. It can support multiply end nodes, but all end nodes must transmit data at the same frequency so the LG01-N can receive it. For example: if the End node transmits at 868.1Mhz, The LG01-N's RX setting must be 868.1Mhz so to receive this packet.

2/ It works only for one DR at a time. DR specifies the Spreading Factor and Bandwidth. In LG01-N, even the rx frequency match , if DR doesn't match, it still can't get the sensor data.

3/ LoRaWAN compatible issue

In LoRaWAN protocol, the LoRaWAN end nodes send data in a hopping frequency. Since LG01-N only supports one single frequency, it will only be able to receive the packets sent from the same radio parameters (frequency & DR) in LG01-N.

For example, in EU868, a standard LoRaWAN device may send the data in eight frequencies with different Frequency & SF, such as:

```
LMIC_setupChannel(0, 868100000, DR_RANGE_MAP(DR_SF12, DR_SF7), BAND_CENTI); // g-band
LMIC_setupChannel(1, 868300000, DR_RANGE_MAP(DR_SF12, DR_SF7B), BAND_CENTI); // g-band
LMIC_setupChannel(2, 868500000, DR_RANGE_MAP(DR_SF12, DR_SF7), BAND_CENTI); // g-band
LMIC_setupChannel(3, 867100000, DR_RANGE_MAP(DR_SF12, DR_SF7), BAND_CENTI); // g-band
LMIC_setupChannel(4, 867300000, DR_RANGE_MAP(DR_SF12, DR_SF7), BAND_CENTI); // g-band
LMIC_setupChannel(5, 867500000, DR_RANGE_MAP(DR_SF12, DR_SF7), BAND_CENTI); // g-band
LMIC_setupChannel(6, 867700000, DR_RANGE_MAP(DR_SF12, DR_SF7), BAND_CENTI); // g-band
LMIC_setupChannel(7, 867900000, DR_RANGE_MAP(DR_SF12, DR_SF7), BAND_CENTI); // g-band
LMIC_setupChannel(8, 868800000, DR_RANGE_MAP(DR_FSK, DR_FSK), BAND_MILLI); // g2-band
```

So the LG01-N will only able to receive the 868100000, SF7 packet and will not receive others. Means only one packet will arrive the TTN server in every 8 packet sent from the LoRaWAN end node.

If user wants to receive all packets from LoRaWAN end node, user needs to set up the LoRaWAN node to send packets in a single frequency.

4/ Downlink & OTAA issue

According to the LoRaWAN class A spec, the end node will open two receive windows to get the message from LoRaWAN server for OTAA or downlink function. These two receive windows are quite short (milliseconds), if LoRa packet from the gateway can't reach End Node in the receive window time, the end node won't get the rx message and Downlink / OTAA won't work.

In our example, the Arduino LMIC library is modified to enlarge the RX window to let OTAA & downlink works.

4 Example 2: Test with a MQTT IoT Server


This example describes how to use LG01-N, LoRa Shield & LoRa GPS Shield to set up a LoRa network and connect it to [ThingSpeak IoT Server](#).

A Video Instruction of this example can be found at this url: <https://youtu.be/asoNyFYZam0>

4.1 Typology and Data Flow

The network topology and dataflow for the example is as below:


Topology for ThingSpeak Connection:



In next section we will start to configure for this example.

4.2 Set up sensor channels in ThingSpeak

Step 1: Log in ThingSpeak and set up channels




The screenshot shows the ThingSpeak interface. At the top, there's a navigation bar with links for 'Channels', 'Apps', 'Community', 'Support', 'Commercial Use', 'How to Buy', 'Account', and 'Sign Out'. Below the navigation bar, the main area is titled 'My Channel'. On the left, there's a 'New Channel' button. In the center, there's a table with columns for 'Name', 'Type', 'Last Value', 'Created', and 'Updated'. A red arrow labeled '1' points to the 'Channels' dropdown menu, which is open to show 'My Channels', 'Watched Channels', and 'Public Channels'. Another red arrow labeled '2' points to the 'New Channel' button. To the right of the table, there's a 'Help' section with instructions on how to collect data from a ThingSpeak channel. It includes links to 'create channels', 'explore and transform data', and 'ThingSpeak Channels'. Below the help section, there's an 'Examples' section with a list of Arduino boards and an 'Upgrade' section.

Set up two channels:

Field 1: Temperature


Field 2: Humidity



The screenshot shows the 'New Channel' setup page. The 'Name' field is filled with 'Test from the DHT11 and Flame sensor' and the 'Description' field is filled with 'MQTT example'. The 'Field 1' and 'Field 2' fields are highlighted with a red border. The 'Field 3' through 'Field 8' and 'Metadata' fields are empty. The 'Help' section on the right provides information about channels and channel settings. It includes sections for 'Channel Settings' and 'Metadata'.

Step 2: Get MQTT keys for these channels.

Go to Account → My profile and get the [MQTT API Key](#)



ThingSpeak™ Channels Apps Community Support Commercial Use How to Buy Account Sign Out

Edit MathWorks Account settings
Edit MathWorks community information

ThingSpeak settings

Time Zone UTC Change Time Zone

User API Key eQU8LUU0JQKX26NR Generate New API Key

MQTT API Key BYR3I5ECL787PHG9 Password of MQTT Server Generate New MQTT API Key

API Requests

- Time zone is used when displaying data in your ThingSpeak apps.
- User API key is required to create and manage channels.
- MQTT API key is required to subscribe to channel feeds.

Get Channel List
GET https://api.thingspeak.com/channels.json?api_key=eQU8LUU0JQKX26NR

Create a Channel
POST https://api.thingspeak.com/channels.json?api_key=eQU8LUU0JQKX26NR&name=New Channel

Clear a Channel Feed
DELETE https://api.thingspeak.com/channels/CHANNEL_ID/feeds.json?api_key=eQU8LUU0JQKX26NR

Delete a Channel
DELETE https://api.thingspeak.com/channels/CHANNEL_ID?api_key=eQU8LUU0JQKX26NR


Update Channel Metadata
PUT https://api.thingspeak.com/channels.json?api_key=eQU8LUU0JQKX26NR&name=Changed Channel Name

Go to channel page: get the sensor channel:

Channel ID: This is the remote Channel ID in ThingSpeak

Author: User Name for MQTT connection

Write API Key: API key for each channel



ThingSpeak™ Channels Apps Community Support Commercial Use How to Buy Account Sign Out

Test from the DHT11 and Flame sensor

Channel ID 682338 Remote Channel
Author engineerin User Name of MQTT Server
Access: Private

Private View Public View Channel Settings Sharing API Keys Data Import / Export

Write API Key

Key EVDKI16NV993M4XS
Generate New Write API Key

Help

API keys enable you to write data to a channel or read data from a private channel. API keys are auto-generated when you create a new channel.

API Keys Settings

- **Write API Key:** Use this key to write data to a channel. If you feel your key has been compromised, click [Generate New Write API Key](#).
- **Read API Keys:** Use this key to allow other people to view your private channel feeds and charts. Click [Generate New Read API Key](#) to generate an additional read key for the channel.
- **Note:** Use this field to enter information about channel read keys. For example, add notes to keep track of users with access to your channel.

Read API Keys

Key RU6YWIVTLU44X8M

API Requests

Update a Channel Feed

4.3 Simulate MQTT uplink via PC's MQTT tool


This step is not necessary, it just to help user to understand the MQTT protocol and simulate the MQTT connection to ThingSpeak. And check if the account info is valid and correct.

In the PC, download and install [MQTT.fx](#). Open MQTT.fx and configure add a new MQTT client, as below:

Broker Address: mqtt.thingspeak.com


Broker Port: 1883

Client ID: User Defined




After add the profile, connect it and publish to the corresponding Channel with correct API key.

MQTT API see [this document](#):



If update successful, we can see the update in the channel:



4.4 Try MQTT Publish with LG01-N Linux command

This step is also not necessary; it is to show the basic command used for MQTT connection and will help for further debug when connection fails.

First, we need to make sure the LG01-N has internet access. We can log in the SSH and ping an Internet address and see if there is reply. As below:

```
172.31.255.254 - SecureCRT
文件(F) 编辑(E) 查看(V) 选项(O) 传输(T) 脚本(S) 工具(L) 帮助(H)
阿里云_美国服务器 | 172.31.255.254
root@dragino-146d78:~# ping www.163.com
PING www.163.com (58.63.233.35): 56 data bytes
64 bytes from 58.63.233.35: seq=0 ttl=54 time=8.231 ms
64 bytes from 58.63.233.35: seq=1 ttl=54 time=8.709 ms
64 bytes from 58.63.233.35: seq=2 ttl=54 time=8.313 ms
64 bytes from 58.63.233.35: seq=3 ttl=54 time=7.953 ms
64 bytes from 58.63.233.35: seq=4 ttl=54 time=8.539 ms
^C
--- www.163.com ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 7.953/8.349/8.709 ms
root@dragino-146d78:~#
```

LG01-N has built-in Linux utility **mosquitto_pub**. We can use this command to publish the data to ThingSpeak.

The command to update a feed is as below:

```
mosquitto_pub -h mqtt.thingspeak.com -p 1883 -u dragino -P QZXTxxxxxO2J -i
dragino_Client -t channels/200893/publish/B9Z0R25QNVEBKIFY -m
"field1=34&field2=89&status=MQTTPUBLISH"
```

(Make sure the “” is included, otherwise only one data will be uploaded)

Below is the output window:

```
172.31.255.254 - SecureCRT
文件(F) 编辑(E) 查看(V) 选项(O) 传输(T) 脚本(S) 工具(L) 帮助(H)
172.31.255.254
root@dragino-146d78:~# mosquitto_pub -h mqtt.thingspeak.com -p 1883 -u dragino -P Q
ZXTxxxxxO2J -i dragino_Client -t channels/200893/publish/B9Z0R25QNVEBKIFY -m "
field1=34&field2=89&status=MQTTPUBLISH"
root@dragino-146d78:~#
```

After running this command, we can see the data are updated to ThingSpeak, which has same result as what we did at mqtt.fx.


So we success to use LG01-N to uplink data to ThingSpeak, the **mosquitto_pub** command is executed in the Linux side, finally, we will have to call **mosquitto_pub** command while the LoRa sensor data arrive. We will explain how to do that in next step.

4.5 Configure LG01-N Gateway

4.5.1 Publish Logic

In LG01-N (firmware version > LG02_LG08--build-v5.1.1545908833-20181227-1908), there is a built-in script to process the MQTT data. The logic of this flow is as below:


How MQTT script works:



Operate Principle:

- > LoRa End Node sends the data to gateway in specify format: <node_ID>value
- > Gateway get the data and will put the data in corresponding files under /var/iot/channels.
- > MQTT Process Script will publish data to remote channel according to the pre-configure mapping

Step1: Configure LG01-N to act as MQTT mode



LoRa Gateway Settings

Configuration to communicate with LoRa devices and LoRaWAN server

LoRaWAN Server Settings

IoT Service	LoRaRAW forward to MQTT server
Debug Level	Little message output
Service Provider	The Things Network

Step2: Configure MQTT server info

MQTT Server Settings

Configuration to communicate with MQTT server

Configure MQTT Server

Select Server	ThingSpeak MQTT
User Name [-u]	dragino1
Password [-P]	32W6GMEXYTEQ7049
Client ID [-i]	dragino_Client

In step 2, we have below settings:

- ✓ UserName[-u option]: Input Author (user name for MQTT Connection)
- ✓ Password[-P option]: Input MQTT API key

- ✓ Client_ID[-i]: dragino_Client (can put any string)
- ✓ Because we choose Thingspeak so we have below pre-set options but not show in web
 - Broker Address[-h]: mqtt.thingspeak.com
 - Broker Port[-p]: 1883
 - Topic Format[-t]: channels/CHANNEL/publish/WRITE_API.
 - Data String Format[-m]: DATA&status=MQTTPUBLISH

And we configure this channel:

- ✓ Local Channel ID: 10009
- ✓ Remote Channel ID: 396640
- ✓ Write_api_key: Write API key for this channel.

In the mqtt script, the upper **CHANNEL** will be replaced by the parameter (remote channel in IoT server). and the **WRITE_API** will be replaced by the settings in write api key. The **DATA** will be replaced by the value stored in the /var/iot/channels/LOCAL_CHANNEL file.

MQTT script will keep checking the files in /var/iot/channels/. If it finds a match Local channel, then the MQTT script will send out the data of this local channel to a remote channel according to the setting above.

User can also enable MQTT debug level and run logread in Linux console to see how the mqtt command is composed. Below is an example:

```

Tue Nov 27 15:07:43 2018 kern.notice syslog: [IOT-MQTT]: Found Local channels:
Tue Nov 27 15:07:49 2018 kern.notice syslog: [IOT-MQTT]: Check for sensor update
Tue Nov 27 15:07:49 2018 kern.notice syslog: [IOT-MQTT]: Found Local channels:
Tue Nov 27 15:07:55 2018 kern.notice syslog: [IOT-MQTT]: Check for sensor update
Tue Nov 27 15:07:55 2018 kern.notice syslog: [IOT-MQTT]: Found Local channels:
Tue Nov 27 15:07:59 2018 kern.notice syslog: [IOT-MQTT]: Internet Connection Check: FAIL
Tue Nov 27 15:08:01 2018 kern.notice syslog: [IOT-MQTT]: Check for sensor update
Tue Nov 27 15:08:01 2018 kern.notice syslog: [IOT-MQTT]: Found Local channels:
Tue Nov 27 15:08:02 2018 kern.notice syslog: [IOT-MQTT]: DNS Resolve Check: FAIL
Tue Nov 27 15:08:02 2018 kern.notice syslog: [IOT-MQTT]: Internet Connection Check: FAIL
Tue Nov 27 15:08:03 2018 kern.notice syslog: [IOT-MQTT]: Topic Format: v1/USERNAME/things/CLIENTID/data/CHANNEL
Tue Nov 27 15:08:03 2018 kern.notice syslog: [IOT-MQTT]: Data Format: DATA
Tue Nov 27 15:08:09 2018 kern.notice syslog: [IOT-MQTT]: Check for sensor update
Tue Nov 27 15:08:09 2018 kern.notice syslog: [IOT-MQTT]: Found Local channels: 100
Tue Nov 27 15:08:09 2018 kern.notice syslog: [IOT-MQTT]: Find Local channel for 100
Tue Nov 27 15:08:09 2018 kern.notice syslog: [IOT-MQTT]: [ - ] v1/e74b78d9-3858-11e7-afce-8d5fd2a310a7/things/2b1fab30-3859-11e7-afce-8d5fd2a310a7/data/0
Tue Nov 27 15:08:09 2018 kern.notice syslog: [IOT-MQTT]: [ -m] temp,c=30.2
root@dragino-193a18:#

```

4.5.2 Configure LG01-N's Radio frequency

Now we should configure LG01-N's radio parameter to receive the LoRaWAN packets. We are using 868.0Mhz (868000000 Hz) as below:

DRAGINO

www.dragino.com

dragino-1893c4 Status System Network Service Logout

Latitude: 22.73
Longitude: 114.23
Radio Power (Unit dBm): range 5 ~ 20 dBm

Radio Settings

Radio settings for Channel

Frequency (Unit Hz): 868000000 (highlighted by red box, labeled 1)

Spreading Factor: SF7 (highlighted by red box, labeled 2)

Coding Rate: 4/5

Signal Bandwidth: 125 kHz

Preamble Length: 8
Length range: 6 ~ 65536


LoRa Sync Word: 52
Value 52(0x34) for LoRaWAN

Encryption Key: [Encryption Key]

Buttons:
Save & Apply (blue button, labeled 3)
Save (green button)
Reset (red button)

4.6 Create LoRa Shield End Node

4.6.1 Hardware Connection



There are three sensors connect to the LoRa Shield + UNO. These sensors are flame sensors, DHT11 (Temperature & Humidity sensor) and Relay. Please use the connection as we show in the photo.

Note: There is a trick above, the relay is connected to VIN. In this case, The UNO can only be power via USB port. If need to power via DC power adapter, please use another 5v pin to power relay.

Upload [this sketch](#) to the UNO, this sketch will send temperature and humidity data to gateway at every 60 seconds. If there is a flame detect, it will then immediately send the value to gateway and then upload to the IoT Server.

4.6.2 Test with uplink

After we upload the sketch to UNO, we can see below output from Arduino

```

MQTT_DHT11_and_Flame_sensor_Client_update_to_ThingSpeak.ino
COM12 (Arduino/Genuino Uno)

The temperature and humidity:
[24.00°C, 65.00%]
The packet is send successful
#####
COUNT=4 #####
The temperature and humidity:
[24.00°C, 65.00%]
The packet is send successful
#####
COUNT=5 #####
The temperature and humidity:
[24.00°C, 65.00%]
The packet is send successful
#####
COUNT=6 #####
The temperature and humidity:
[24.00°C, 65.00%]
The packet is send successful
#####
COUNT=7 #####
The temperature and humidity:
[24.00°C, 65.00%]
The packet is send successful
#####
COUNT=8 #####
avrduke done. Thank you.

```


And we can see the logread of gateway as below, means the packet arrive gateway:

```

10.130.2.125 - [2020-01-20T02:52:58+0000] user.notice root: [iot.mqtt]: Find Match entry for 3678
Sun Jan 20 02:52:58 2019 user.notice root: [iot.mqtt]: [-t] channel1=682338,publish/EVDK11uNv9934X5
Sun Jan 20 02:52:58 2019 user.notice root: [iot.mqtt]: [-e] Field1=26,0,0#Field2=01,0#0x00#status=MQTT_PUBLISH
Sun Jan 20 02:53:57 2019 daemon.info ig01_dkt_fwm[26279]: RXTE- receive(HEX):c3c3637383e6669656c64113d32362e30266669656c643
23d6312e30
Sun Jan 20 02:53:58 2019 user.notice root: [iot.mqtt]: Find Match entry for 3678
Sun Jan 20 02:53:58 2019 user.notice root: [iot.mqtt]: [-t] channel1=682338,publish/EVDK11uNv9934X5
Sun Jan 20 02:53:58 2019 user.notice root: [iot.mqtt]: [-e] Field1=26,0,0#Field2=01,0#0x00#status=MQTT_PUBLISH
Sun Jan 20 02:54:57 2019 daemon.info ig01_dkt_fwm[26279]: RXTE- receive(HEX):c3c3637383e6669656c64113d32362e30266669656c643
23d6312e30
Sun Jan 20 02:54:58 2019 user.notice root: [iot.mqtt]: Find Match entry for 3678
Sun Jan 20 02:54:58 2019 user.notice root: [iot.mqtt]: [-t] channel1=682338,publish/EVDK11uNv9934X5
Sun Jan 20 02:54:58 2019 user.notice root: [iot.mqtt]: [-e] Field1=26,0,0#Field2=01,0#0x00#status=MQTT_PUBLISH
Sun Jan 20 02:55:19 2019 daemon.info ig01_dkt_fwm[26279]: RXTE- receive(HEX):c3c3637383e6669656c64113d32362e30266669656c643
23d6312e30
Sun Jan 20 02:55:22 2019 user.notice root: [iot.mqtt]: Find Match entry for 3678
Sun Jan 20 02:55:22 2019 user.notice root: [iot.mqtt]: [-t] channel1=682338,publish/EVDK11uNv9934X5
Sun Jan 20 02:55:22 2019 user.notice root: [iot.mqtt]: [-e] Field1=26,0,0#Field2=01,0#0x00#status=MQTT_PUBLISH
Sun Jan 20 02:55:58 2019 daemon.info ig01_dkt_fwm[26279]: RXTE- receive(HEX):c3c3637383e6669656c64113d32362e30266669656c643
23d6312e30
Sun Jan 20 02:55:58 2019 user.notice root: [iot.mqtt]: Find Match entry for 3678
Sun Jan 20 02:55:58 2019 user.notice root: [iot.mqtt]: [-t] channel1=682338,publish/EVDK11uNv9934X5
Sun Jan 20 02:55:58 2019 user.notice root: [iot.mqtt]: [-e] Field1=26,0,0#Field2=01,0#0x00#status=MQTT_PUBLISH
Sun Jan 20 02:56:56 2019 daemon.info ig01_dkt_fwm[26279]: RXTE- receive(HEX):c3c3637383e6669656c64113d32362e30266669656c643
23d6312e30
Sun Jan 20 02:56:58 2019 user.notice root: [iot.mqtt]: Find Match entry for 3678
Sun Jan 20 02:56:58 2019 user.notice root: [iot.mqtt]: [-t] channel1=682338,publish/EVDK11uNv9934X5
Sun Jan 20 02:56:58 2019 user.notice root: [iot.mqtt]: [-e] Field1=26,0,0#Field2=01,0#0x00#status=MQTT_PUBLISH
Sun Jan 20 02:56:58 2019 user.notice root: [iot.mqtt]: Find Match entry for 3678
Sun Jan 20 02:56:58 2019 user.notice root: [iot.mqtt]: [-t] channel1=682338,publish/EVDK11uNv9934X5
Sun Jan 20 02:56:58 2019 user.notice root: [iot.mqtt]: [-e] Field1=26,0,0#Field2=01,0#0x00#status=MQTT_PUBLISH
Sun Jan 20 02:57:04 2019 user.notice root: [iot.mqtt]: Find Match entry for 3678
Sun Jan 20 02:57:04 2019 user.notice root: [iot.mqtt]: [-t] channel1=682338,publish/EVDK11uNv9934X5
Sun Jan 20 02:57:04 2019 user.notice root: [iot.mqtt]: [-e] Field1=26,0,0#Field2=01,0#0x00#status=MQTT_PUBLISH
Sun Jan 20 02:57:58 2019 user.notice root: [iot.mqtt]: RXTE- receive(HEX):c3c3637383e6669656c64113d32362e30266669656c643
23d6312e30
Sun Jan 20 02:58:04 2019 user.notice root: [iot.mqtt]: Find Match entry for 3678
Sun Jan 20 02:58:04 2019 user.notice root: [iot.mqtt]: [-t] channel1=682338,publish/EVDK11uNv9934X5
Sun Jan 20 02:58:04 2019 user.notice root: [iot.mqtt]: [-e] Field1=26,0,0#Field2=01,0#0x00#status=MQTT_PUBLISH
Sun Jan 20 02:58:04 2019 user.notice root: [iot.mqtt]: RXTE- receive(HEX):c3c3637383e6669656c64113d32362e30266669656c643
23d6312e30
Sun Jan 20 02:59:04 2019 user.notice root: [iot.mqtt]: Find Match entry for 3678
Sun Jan 20 02:59:04 2019 user.notice root: [iot.mqtt]: [-t] channel1=682338,publish/EVDK11uNv9934X5
Sun Jan 20 02:59:04 2019 user.notice root: [iot.mqtt]: [-e] Field1=26,0,0#Field2=01,0#0x00#status=MQTT_PUBLISH
Sun Jan 20 02:59:58 2019 user.notice root: [iot.mqtt]: RXTE- receive(HEX):c3c3637383e6669656c64113d32362e30266669656c643
23d6312e30
Sun Jan 20 03:01:04 2019 user.notice root: [iot.mqtt]: Find Match entry for 3678
Sun Jan 20 03:01:04 2019 user.notice root: [iot.mqtt]: [-t] channel1=682338,publish/EVDK11uNv9934X5
Sun Jan 20 03:01:04 2019 user.notice root: [iot.mqtt]: [-e] Field1=26,0,0#Field2=01,0#0x00#status=MQTT_PUBLISH
Sun Jan 20 03:01:04 2019 user.notice root: [iot.mqtt]: RXTE- receive(HEX):c3c3637383e6669656c64113d32362e30266669656c643
23d6312e30
Sun Jan 20 03:01:04 2019 user.notice root: [iot.mqtt]: Find Match entry for 3678
Sun Jan 20 03:01:04 2019 user.notice root: [iot.mqtt]: [-t] channel1=682338,publish/EVDK11uNv9934X5
Sun Jan 20 03:01:04 2019 user.notice root: [iot.mqtt]: [-e] Field1=26,0,0#Field2=01,0#0x00#status=MQTT_PUBLISH
Sun Jan 20 03:01:04 2019 user.notice root: [iot.mqtt]: RXTE- receive(HEX):c3c3637383e6669656c64113d32362e30266669656c643
23d6312e30
Sun Jan 20 03:01:58 2019 daemon.info ig01_dkt_fwm[26279]: RXTE- receive(HEX):c3c3637383e6669656c64113d32362e30266669656c643
23d6312e30
Sun Jan 20 03:02:04 2019 user.notice root: [iot.mqtt]: RXTE- receive(HEX):c3c3637383e6669656c64113d32362e30266669656c643
23d6312e30
Sun Jan 20 03:02:04 2019 user.notice root: [iot.mqtt]: [-t] channel1=682338,publish/EVDK11uNv9934X5
Sun Jan 20 03:02:04 2019 user.notice root: [iot.mqtt]: [-e] Field1=26,0,0#Field2=01,0#0x00#status=MQTT_PUBLISH

```


Finally, we can see on the ThingSpeak:



4.6.3 Test with interrupt by flame detect

The DO pin of Flame sensor is high in normal state. When a flame is detected, the DO pin of Flame sensor will become low, then, the UNO generates an external interrupt, and immediately uploads the temperature and humidity to the server.

The DO pin of Flame sensor is low when a flame is detected, and we can see on the Serial Monitor:




```

MQTT_DHT11_and_Flame_sensor_Client_update_to_ThingSpeak_.| Arduino 1
文件 帮助 项目 工具 附录
MQTT_DHT11_and_Flame_sensor_Client_update_to_ThingSpeak_
73 void fire() // Interrupt
74 {
75     Serial.println("Have fire,
76     dhtTem();
77     dhtWrite();
78     LoRa.beginPacket();
79     LoRa.print((char *)datasen
80     LoRa.endPacket();
81 }
82
83 void SendData()
84 {
85
86
87
88
89
avrduke done. Thank you.

```

The temperature and humidity:
[26.00°C, 61.00%]
The packet is send successful
COUNT=2 #####
The temperature and humidity:
[26.00°C, 61.00%]
The packet is send successful
COUNT=3 #####
The temperature and humidity:
[26.00°C, 61.00%]
The packet is send successful
COUNT=4 #####
The temperature and humidity:
[26.00°C, 59.00%]
The packet is send successful
Have fire, the temperature is send
The temperature and humidity:
[26.00°C, 59.00%]

Similarly, we can see the logread of gateway via SSH access:



```


10.130.2.125 - SecureCRT
文件(F) 编辑(E) 查看(V) 选项(O) 传输(T) 脚本(S) 工具(L) 帮助(H)
10.130.2.125
Sun Jan 20 02:52:58 2019 user.notice root: [IOT-MQTT]: Find Match Entry for 5678
Sun Jan 20 02:52:58 2019 user.notice root: [IOT-MQTT]: [-t] channels/682338/publish/EVDK11ENV993MAXS
Sun Jan 20 02:52:58 2019 user.notice root: [IOT-MQTT]: [-m] Field1=26,0&Field1=d2-61,0&status=MQTT_PUBLISH
Sun Jan 20 02:53:57 2019 daemon.info 1901-pkt-fwd[26279]: RXTx Receive(HEX):3c353637383e6669656c64313d32362e30266669656c643
23d3632e30
Sun Jan 20 02:53:58 2019 user.notice root: [IOT-MQTT]: Find Match Entry for 5678
Sun Jan 20 02:53:58 2019 user.notice root: [IOT-MQTT]: [-t] channels/682338/publish/EVDK11ENV993MAXS
Sun Jan 20 02:53:58 2019 user.notice root: [IOT-MQTT]: [-m] Field1=26,0&Field1=d2-61,0&status=MQTT_PUBLISH
Sun Jan 20 02:54:57 2019 daemon.info 1901-pkt-fwd[26279]: RXTx Receive(HEX):3c353637383e6669656c64313d32362e30266669656c643
23d35392e30
Sun Jan 20 02:54:58 2019 user.notice root: [IOT-MQTT]: Find Match Entry for 5678
Sun Jan 20 02:54:58 2019 user.notice root: [IOT-MQTT]: [-t] channels/682338/publish/EVDK11ENV993MAXS
Sun Jan 20 02:54:58 2019 user.notice root: [IOT-MQTT]: [-m] Field1=26,0&Field1=d2-59,0&status=MQTT_PUBLISH
Sun Jan 20 02:55:19 2019 daemon.info 1901-pkt-fwd[26279]: RXTx Receive(HEX):3c353637383e6669656c64313d32362e30266669656c643
23d3532e30
Sun Jan 20 02:55:22 2019 user.notice root: [IOT-MQTT]: Find Match Entry for 5678
Sun Jan 20 02:55:22 2019 user.notice root: [IOT-MQTT]: [-t] channels/682338/publish/EVDK11ENV993MAXS
Sun Jan 20 02:55:22 2019 user.notice root: [IOT-MQTT]: [-m] Field1=26,0&Field1=d2-59,0&status=MQTT_PUBLISH
Sun Jan 20 02:55:58 2019 daemon.info 1901-pkt-fwd[26279]: RXTx Receive(HEX):3c353637383e6669656c64313d32362e30266669656c643
23d35382e30
Sun Jan 20 02:55:58 2019 user.notice root: [IOT-MQTT]: Find Match Entry for 5678
Sun Jan 20 02:55:58 2019 user.notice root: [IOT-MQTT]: [-t] channels/682338/publish/EVDK11ENV993MAXS
Sun Jan 20 02:55:58 2019 user.notice root: [IOT-MQTT]: [-m] Field1=26,0&Field1=d2-59,0&status=MQTT_PUBLISH
Sun Jan 20 02:56:58 2019 daemon.info 1901-pkt-fwd[26279]: RXTx Receive(HEX):3c353637383e6669656c64313d32362e30266669656c643
23d3532e30
Sun Jan 20 02:57:04 2019 user.notice root: [IOT-MQTT]: Find Match Entry for 5678
Sun Jan 20 02:57:04 2019 user.notice root: [IOT-MQTT]: [-t] channels/682338/publish/EVDK11ENV993MAXS
Sun Jan 20 02:57:04 2019 user.notice root: [IOT-MQTT]: [-m] Field1=26,0&Field1=d2-60,0&status=MQTT_PUBLISH
Sun Jan 20 02:57:58 2019 daemon.info 1901-pkt-fwd[26279]: RXTx Receive(HEX):3c353637383e6669656c64313d32362e30266669656c643
23d35382e30
Sun Jan 20 02:58:04 2019 user.notice root: [IOT-MQTT]: Find Match Entry for 5678
Sun Jan 20 02:58:04 2019 user.notice root: [IOT-MQTT]: [-t] channels/682338/publish/EVDK11ENV993MAXS
Sun Jan 20 02:58:04 2019 user.notice root: [IOT-MQTT]: [-m] Field1=26,0&Field1=d2-59,0&status=MQTT_PUBLISH
Sun Jan 20 02:58:58 2019 daemon.info 1901-pkt-fwd[26279]: RXTx Receive(HEX):3c353637383e6669656c64313d32362e30266669656c643
23d3632e30
Sun Jan 20 03:00:04 2019 user.notice root: [IOT-MQTT]: Find Match Entry for 5678
Sun Jan 20 03:00:04 2019 user.notice root: [IOT-MQTT]: [-t] channels/682338/publish/EVDK11ENV993MAXS
Sun Jan 20 03:00:04 2019 user.notice root: [IOT-MQTT]: [-m] Field1=26,0&Field1=d2-59,0&status=MQTT_PUBLISH
Sun Jan 20 03:00:58 2019 daemon.info 1901-pkt-fwd[26279]: RXTx- Receive(HEX):3c353637383e6669656c64313d32362e30266669656c643
23d35392e30
Sun Jan 20 02:59:04 2019 user.notice root: [IOT-MQTT]: Find Match Entry for 5678
Sun Jan 20 02:59:04 2019 user.notice root: [IOT-MQTT]: [-t] channels/682338/publish/EVDK11ENV993MAXS
Sun Jan 20 02:59:04 2019 user.notice root: [IOT-MQTT]: [-m] Field1=26,0&Field1=d2-62,0&status=MQTT_PUBLISH
Sun Jan 20 02:59:58 2019 daemon.info 1901-pkt-fwd[26279]: RXTx- Receive(HEX):3c353637383e6669656c64313d32362e30266669656c643
23d3632e30
Sun Jan 20 03:01:04 2019 user.notice root: [IOT-MQTT]: Find Match Entry for 5678
Sun Jan 20 03:01:04 2019 user.notice root: [IOT-MQTT]: [-t] channels/682338/publish/EVDK11ENV993MAXS
Sun Jan 20 03:01:04 2019 user.notice root: [IOT-MQTT]: [-m] Field1=26,0&Field1=d2-59,0&status=MQTT_PUBLISH
Sun Jan 20 03:01:58 2019 daemon.info 1901-pkt-fwd[26279]: RXTx- Receive(HEX):3c353637383e6669656c64313d32362e30266669656c643
23d35392e30
Sun Jan 20 03:01:58 2019 user.notice root: [IOT-MQTT]: Find Match Entry for 5678
Sun Jan 20 03:01:58 2019 user.notice root: [IOT-MQTT]: [-t] channels/682338/publish/EVDK11ENV993MAXS
Sun Jan 20 03:01:58 2019 user.notice root: [IOT-MQTT]: [-m] Field1=26,0&Field1=d2-59,0&status=MQTT_PUBLISH
Sun Jan 20 03:02:04 2019 user.notice root: [IOT-MQTT]: Find Match Entry for 5678
Sun Jan 20 03:02:04 2019 user.notice root: [IOT-MQTT]: [-t] channels/682338/publish/EVDK11ENV993MAXS
Sun Jan 20 03:02:04 2019 user.notice root: [IOT-MQTT]: [-m] Field1=26,0&Field1=d2-61,0&status=MQTT_PUBLISH

```

Detected the fire

Transmission interval is one minute

Finally, we can see on the ThingSpeak:




4.6.4 Test with downlink

The http downlink feature is now support since firmware LG02_LG08--build--v5.2.1560931576--20190619-1607.

ThingSpeak downlink command can be found in TalkBack App.

The **Command String input box** is the command you want to send to LoRa device.



The screenshot shows the ThingSpeak TalkBack app interface. In the top navigation bar, 'TalkBack' is selected. A dropdown menu is open under 'TalkBack', with 'TalkBack' highlighted. Below the dropdown, there's a table titled 'Commands' with one row: Position 1, Command ID 16007288, and Command string DownlinkTest. A red box surrounds the 'Save' button in the 'Position' column. To the right of the table, several API endpoints are listed:


- Add a TalkBack Command**: POST <https://api.thingspeak.com/talkbacks/30660/commands.json> api_key=JZ3X4Y9fTCZNH9YO
- Get a TalkBack Command**: GET https://api.thingspeak.com/talkbacks/30660/commands/COMMAND_ID.json?api_key=JZ3X4Y9fTCZNH9YO
- Update a TalkBack Command**: PUT https://api.thingspeak.com/talkbacks/30660/commands/COMMAND_ID.json api_key=JZ3X4Y9fTCZNH9YO
- Execute the Next TalkBack Command**: POST <https://api.thingspeak.com/talkbacks/30660/commands/execute.json> api_key=JZ3X4Y9fTCZNH9YO
- Update a Channel and Execute the Next TalkBack Command**: POST <https://api.thingspeak.com/update.json> field1=70 api_key=PARXVY59P5QEY6S talkback_key=JZ3X4Y9fTCZNH9YO
- Get the Last Executed Command**: GET https://api.thingspeak.com/talkbacks/30660/commands/last.json?api_key=JZ3X4Y9fTCZNH9YO

Execute The next Talkback Command is the API to get one command from the commands queue.

We can test in the web with this API. Format is:

https://api.thingspeak.com/talkbacks/XXXXXX/commands/execute.json?api_key=XXXXXXXXXX

Result as below:




```

id: 16007322
command_string: "DownlinkTest"
position: null
executed_at: "2019-06-19T13:35:03Z"
created_at: "2019-06-19T13:34:59Z"
  
```

We can also test this API in LG01-N Linux console:

By using:


`curl -k https://api.thingspeak.com/talkbacks/XXXXXX/commands/execute.json?api_key=XXXXXXXXXX`



```

root@dragino-1b9e2c:~# curl -k https://api.thingspeak.com/talkbacks/30660/commands/execute.json?api_key=JZ3X4Y9fTCZNH9YO
root@dragino-1b9e2c:~# curl -k https://api.thingspeak.com/talkbacks/30660/commands/execute.json?api_key=JZ3X4Y9fTCZNH9YO
{"id":16007340,"command_string":"DownlinkTest","position":null,"executed_at":"2019-06-19T13:40:02Z","created_at":"2019-06-19T13:39:58Z"}
  
```

To get this result automatically in LG01-P and send out via LoRa, we can configure as below:



HTTP / HTTPS

http/https connection to IoT Server

General Settings

Enable SSL Connection

Enable HTTP Downlink Forward downlink data via LoRa

Downlink URL

Downlink Datatype


Downlink Parameter

Downlink Poll Interval unit:seconds.

Save & Apply

- Because URL is https, So need to Enable SSL Connection
- Downlink URL use the URL we use in Web and Curl
- Downlink datatype for ThingSpeak is Json.
- Downlink Parameter is command_string. We will fetch the value of `command_string` from the downlink data string.
- LG01-N will poll the URL every 5 seconds. When there is valid command_string found, it will send out via LoRa (Radio parameter is defined in LoRaWAN gateway Radio settings or Radio2 settings for LG02)

Result in the LoRa Shield:



```
The temperature and humidity:  
[30.00°C, 86.00%]  
Packet Sent  
##### COUNT=26 #####  
The temperature and humidity:  
[30.00°C, 87.00%]  
Packet Sent  
Received packet : DownlinkTest
```

Autoscroll No line ending 9600 baud Clear output

4.7 Conclusion and limitation

4.7.1 Overview for the example

This example shows how to set up a simple LoRa network with ThingSpeak IoT server. In this example, we use the raw LoRa protocol (private protocol) for transmission. It is simpler compare via LoRaWAN protocol

There are some frequently ask points for the example:

1/ Difference between LoRaWAN & Private LoRa protocol:

- The private LoRa protocol here doesn't have MAC control/management, (of course developer can develop this). In LoRaWAN protocol, this feature is supported already.
- The transmission is unencrypted in this example, user can see the data in gateway. In LoRaWAN, the transmission is designed in AES encryption.
- Private LoRa protocol means the gateway only works with specify LoRa End node which runs the same protocol, the gateway can't work with a standard LoRaWAN devices.
- Private LoRa protocol doesn't need the LoRaWAN IoT Server. Gateway can send data to user defined IoT server, in terms the gateway and the server can communicate with each other.
- User can more features in the private protocol such as MAC control, encryption, that is how LoRaWAN protocol comes, the advantage of LoRaWAN protocol is that it is designed for carrier level use, and developer can use it directly with many features and compatible with the LoRaWAN node from different manufacturers.

5 Order Info

LoRa_IoT_Kit-v2-XXX-YYY

XXX: Frequency Band

433: For Bands: EU433, CN470

868: For Bands: EU868, IN865

915: For Bands: US915, AU915, AS923, KR920

YYY: 4G Cellular Option

EC25-E: EMEA, Korea, Thailand, India.

EC25-A: North America/ Rogers/AT&T/T-Mobile.

EC25-AU: Latin America, New Zealand, Taiwan

EC25-J: Japan, DOCOMO/SoftBank/ KDDI

More info about valid bands, please see EC25-E product page

(<https://www.quectel.com/product/ec25.htm>)

6 FAQ & Trouble Shooting

6.1 I can't upload sketch to LoRa Shield in MAC OS, shows "dev/cu.usbmodem1421 is not available"

Error Info as below:

```
Arduino: 1.8.3 (Mac OS X), Board: "Arduino/Genuino Uno"
Archiving built core (caching) in:
/var/folders/jq/8fnvlfj90tgbnbcy whole0gn/T/arduino_cache_833512/core/core_arduino
_avr_arduino_fc9a32205aafa27e4eda988d5ed9b7ac.a
Sketch uses 20142 bytes (62%) of program storage space. Maximum is 32256 bytes.
Global variables use 1189 bytes (58%) of dynamic memory, leaving 859 bytes for local variables.
Maximum is 2048 bytes.
Board at /dev/cu.usbmodem1421 is not available
```


The Arduino UNOs in the Kit are clone version and use CH340 USB to serial chip. User has to install the CH340 driver in PC to make it work. Above issue means the MAC OS doesn't have CH340 driver.

6.2 My IoT Kit has the model LG01-P instead of LG01-N, Can I still use this manual.

The gateway part of this manual is for LG01-N, if user has the LG01-P version, please check the [LG01-P gateway manual](#).

6.3 Duplicate library issue while upload in Arduino IDE 1.8.10.

While compile the LMIC library in Arduino IDE 1.8.10. This error will happen:



```
ttn-abp | Arduino 1.8.10
File Edit Sketch Tools Help
ttn-abp
Error compiling for board Arduino/Genuino Uno.

C:\Users\ghiasel\AppData\Local\Temp\ccbUBooN.ltrans0.ltrans.o: In function `calcRxWindow':
C:\Users\ghiasel\Desktop\arduino-1.8.10-windows\arduino-1.8.10\libraries\arduino-lmic-master\src\lmic\lmic.c:406: undefined reference to `table_get_ostime'
C:\Users\ghiasel\Desktop\arduino-1.8.10-windows\arduino-1.8.10\libraries\arduino-lmic-master\src\lmic\lmic.c:408: undefined reference to `table_get_ostime'
C:\Users\ghiasel\AppData\Local\Temp\ccbUBooN.ltrans0.ltrans.o: In function `initDefaultChannels':
C:\Users\ghiasel\Desktop\arduino-1.8.10-windows\arduino-1.8.10\libraries\arduino-lmic-master\src\lmic\lmic.c:564: undefined reference to `table_get_u4'
C:\Users\ghiasel\AppData\Local\Temp\ccbUBooN.ltrans0.ltrans.o: In function `radio_irq_handler':
C:\Users\ghiasel\Desktop\arduino-1.8.10-windows\arduino-1.8.10\libraries\arduino-lmic-master\src\lmic\radio.c:792: undefined reference to `table_get_u2'
C:\Users\ghiasel\AppData\Local\Temp\ccbUBooN.ltrans0.ltrans.o: In function `schedRx12':
C:\Users\ghiasel\Desktop\arduino-1.8.10-windows\arduino-1.8.10\libraries\arduino-lmic-master\src\lmic\lmic.c:1369: undefined reference to `table_get_ostime'
collect2.exe: error: ld returned 1 exit status

Multiple libraries were found for "lmic.h"
  Used: C:\Users\ghiasel\Desktop\arduino-1.8.10-windows\arduino-1.8.10\libraries\arduino-lmic-master
Multiple libraries were found for "SPI.h"
  Used: C:\Users\ghiasel\Desktop\arduino-1.8.10-windows\arduino-1.8.10\hardware\arduino\avr\libraries\SPI
Using library arduino-lmic-master at version 1.5.0 arduino-2 in folder: C:\Users\ghiasel\Desktop\arduino-1.8.10-windows\arduino-1.8.10\libraries\arduino-lmic-master
Using library SPI at version 1.0 in folder: C:\Users\ghiasel\Desktop\arduino-1.8.10-windows\arduino-1.8.10\hardware\arduino\avr\libraries\SPI
exit status 1
Error compiling for board Arduino/Genuino Uno.
```

To solve this, user can modify the file:

`~/Dev/Arduino.app/Contents/Java/hardware/arduino/avr/platform.txt`

, Change the compile flag from `-Os` to `-O2`. Like below:

```
compiler.warning_flags.more=-Wall
compiler.warning_flags.all=-Wall -Wextra

// Default "compiler.path" is correct, change only if you want to override the initial value
compiler.path={runtime.tools.avr-gcc.path}/bin/
compiler.c.cmd=avr-gcc
compiler.c.flags=-c -g -O2 {compiler.warning_flags} -std=gnu11 -ffunction-sections -fdata-sections -MMD -fno-fat-lto-objects
compiler.c.elf.flags={compiler.warning_flags} -O2 -g -fno-fat-lto -fuse-linker-plugin -Wl,--gc-sections
compiler.c.elf.cmd=avr-gcc
compiler.S.flags=-c -g -x assembler-with-cpp -fno-fat-lto -MMD
compiler.cpp.cmd=avr-g++
compiler.cpp.flags=-c -g -O2 {compiler.warning_flags} -std=gnu++11 -fpermissive -fno-exceptions -ffunction-sections -fdata-sections -fno-threadsafe
  cs -Wno-error=narrowing -MMD -fno-fat-lto
compiler.ar.cmd=avr-gcc-ar
compiler.ar.flags=rCS
compiler.objcopy.cmd=avr-objcopy
compiler.objcopy.eep.flags=-O ihex -j .eeprom --set-section-flags=.eeprom=alloc,load --no-change-warnings --change-section-lma .eeprom=0
compilerElf2hex.flags=-O ihex -R .eeprom
```

6.4 How can I set to use CN470 band?

```
11 // #define CFG_as921 1
12 // #define CFG_as923 1
13 // #define CFG_in866 1
14
15 #define LG02_LG01 1
16
17 //US915: DR_SF10=0, DR_SF9=1, DR_SF8=2, DR_SF7=3, DR_SF8C=4
18 //           DR_SF12CR=8, DR_SF11CR=9, DR_SF10CR=10, DR_SF9CR=11, DR_SF8CR=12, DR_SF7CR
19 #if defined(CFG_us915) && defined(LG02_LG01)
20 // CFG_us915 || CFG_as923
21 #define LG02_UPFREQ 902320000
22 #define LG02_DNWREQ 923300000
23 #define LG02_RXSF 3      // DR_SF7 For LG01/LG02 Tx
24 #define LG02_TXSF 8      // DR_SF12CR For LG02/LG02 Rx
25 #elif defined(CFG_eu868) && defined(LG02_LG01)
26 // CFG_eu868
27 //EU868: DR_SF12=0, DR_SF11=1, DR_SF10=2, DR_SF9=3, DR_SF8=4, DR_SF7=5, DR_SF7B=1, DR_FSK, DR_
28 #define LG02_UPFREQ 505300000
29 #define LG02_DNWREQ 505300000
30 #define LG02_RXSF 0      // DR_SF7 For LG01/LG02 Tx
31 #define LG02_TXSF 0      // DR_SF12 For LG02/LG02 Rx
32 #endif
33
```

7 Technical Support

- Support is provided Monday to Friday, from 09:00 to 18:00 GMT+8. Due to different timezones we cannot offer live support. However, your questions will be answered as soon as possible in the before-mentioned schedule.
- Provide as much information as possible regarding your enquiry (product models, accurately describe your problem and steps to replicate it etc) and send a mail to

support@dragino.com

8 Reference

- 1) [LoRaWAN official website. And Technical document for LoRaWAN.](#)
- 2) [LG01-N LoRa Gateway User Manual](#)
- 3) [LoRa Low Energy design guide](#) and [Calculator Tool](#).
- 4) About Distance: [LoRa Modem Design Guide](#)
- 5) [SX1276 download resource](#).
- 6) User Manual: [LG01-N](#), [LoRa Shield](#), [LoRa/GPS Shield](#)